


91-162 Function schematic seat back locking system (coupe)



----- Suction line
 Control line

8 Check valve
 10 Restrictor
 11 Distribution piece
 17 Connection piece
 22 Distribution piece

44 Door contact vacuum switch
 46 Vacuum switch (driver's seat back)
 51 Vacuum element (seat)
 54 Operating rod
 73 Intake manifold

